



## INSTALLATION

We recommend to place the washbasin over the vanity top with silicone at the edges, never use cement glue.

**CAUTION!!** Always install the valve with the rubber parts. If it's necessary, add some silicone also.

**Do not over tighten the valve!!!** The drain hole must follow the dilation movements.

If the concrete is pressed at this point, could appear hairline cracks.

Avoid the directly impact of metal tools on the surface.

Pay attention, if you using silicone will not come in contact with the upper surface of the washbasin, if so, remove it with water shortly.

For further technical information or advice of usage, contact our technical department.

## INSTALLAZIONE

Per il fissaggio del lavabo al piano si suggerisce l'uso di silicone, applicandolo lungo i bordi. Non usare colla per cemento.

**ATTENZIONE!!** Installare sempre la valvola completa delle parti in gomma. Se necessario, aggiungere del silicone.

**Non stringere troppo la valvola!!!** Il foro di scarico deve seguire i movimenti di dilatazione. Se il cemento é sottoposto ad eccessiva pressione in corrispondenza della valvola, possono apparire delle linee di frattura.

Evitare l'impatto diretto di attrezzi metallici con la superficie.

Si prega di fare attenzione nell'uso del silicone affinchè questo non venga in contatto con la superficie superiore del lavabo. Nel caso ciò avvenga, rimuovere il silicone con acqua.

Per ulteriori informazioni tecniche o consigli d'uso, siete invitati a contattare il nostro Ufficio Tecnico.

